

LEWA Service for NIKKISO canned motor pumps in Europe.

Performance and reliability over the entire life cycle



Support with commissioning and fault analysis

Our service technicians assist with the commissioning of the NIKKISO canned motor pump. We also carry out fault analyses for NIKKISO canned motor pumps to identify causes and sources of faults. A cost estimate is always prepared and is free of charge if the repair or purchase of an identical NIKKISO canned motor pump is ordered.



Certified NIKKISO Service

Extensive repairs and maintenance can be carried out in the NIKKISO canned motor pump workshop at the LEWA headquarters in Leonberg. Regular audits of NIKKISO assure the repair and maintenance work according to current NIKKISO standards.



Attachment accessories

The subsequent assembly or subsequent installation of accessories, such as inline filters, external temperature monitoring, etc. can be arranged in our NIKKISO canned motor pump workshop. The CE and ATEX conformity is maintained or is granted directly by NIKKISO.



Modifications

Changes to the materials, the impeller diameter, the nameplate or other modifications may result in the loss of ATEX approval. As a Special Critical Supplier of NIKKISO, we are authorized carry out certain modifications to a NIKKISO canned motor pump while maintaining CE and ATEX conformity.



Repairs & maintenance work

The demand-oriented replacement of wear parts of NIKKISO canned motor pumps, depending on the condition of the individual components, ensures an economic and sustainable repair. As part of the maintenance work, the resistances of the motor windings and sensors are also checked; this can also be carried out on site.



Original NIKKISO spare parts

Compliance with ATEX conformity can only be guaranteed if original NIKKISO spare parts are used. It also ensures that performance, safety and reliability can be maintained over the entire service life.